

TC1000 SPARE PARTS


TC1000



SPARE PARTS LIST


TC1000 SPARE PARTS

LEFT SIDE




TC1000 SPARE PARTS

RIGHT SIDE




TC1000 SPARE PARTS

FRONT SIDE




TC1000 SPARE PARTS

UPPER VIEW



TC1000 SPARE PARTS


PAPER JAM SENSOR GROUP



TC1000 SPARE PARTS


BLADE DRIVE GEAR

**CT18-03 B10
GEAR (z20)**



**COMM0286
BEARING**



**COMM0287
BEARING**



**R 0024
GEAR (z25) + SHAFT**


TC1000 SPARE PARTS

EJECTION GROUP



TC1000 SPARE PARTS

ELECTRONIC BOX



TC1000 SPARE PARTS

SPARE PARTS LIST

P/N	DESCRIPTION	TYPE
COMM0080	Tractor Right Hand	Serie 800
COMM0080/1	Tractor Left Hand	Serie 800
COMM0051	Capacitor	6800 microF 50Vdc
COMM0181	Belt	400 HTD 5M 15
COMM0182	Belt	150 XL 037
COMM0184	Belt	1000 MXL 050
COMM0286	Bearing	6000-2Z
COMM0287	Bearing	6001-2Z
COMM0354	Pin	D=3x25
COMM0357	Pin	Q3x22
COMM0366	Oring	3118
COMM0391	Knob	BT20p M5x10
COMM0394	Gas spring	192937
COMM0400	Brushless Motor	BRL75/1
COMM0401	Brushless Motor	BM 05/3 A069 AHS 006
COMM0402	AC Motor	N56 B4 B14
COMM0403	Amplifier	S5 5 E1 30
COMM0404	Optical Fibre	OF18
COMM0405	Fan	220V 120x120
COMM0406	Proximity (Cutter Group)	AB872C-D2NN8-E2
COMM0407	Capacitor	47KmicroF 63Vdc
COMM0408	Rectifier	400V 35A
COMM0409	Transformer	TMSP600/220-2VS
COMM0410	Keyboard & Display	Tecnu
COMM0411	Motor Driver	BE 25 A 20
COMM0412	Motor Driver	BE 15 A 8
COMM0415	Electronic Board	Fortec-03
COMM0430	Master Switch	MY206-C6
COMM0491	Seeger	ZA3
COMM0495	Microswitch	SS-5GL2

TC1000 SPARE PARTS

P/N	DESCRIPTION
CT12-01 A07	PULLEY TRACTOR
CT18-01 C27/1	SPRING
CT18-01 C34	HANGER
CT18-01 C36	PULLEY TRIMMER
CT18-01 C37	FORK
CT18-01 C38	ROLLER
CT18-01 C40	FLANGE
PD-01 17	ROLLER
T200HP A11	GEAR
T200HP A16	PULLEY TRIMMER
T200HP A19	ROLLER
T200HP A28	UPPER PAPER GUIDE
T200HP A29	LOWER PAPER GUIDE
T200HP A36	PULLEY EJECTION
T200HP A46	PULLEY EJECTION
T200HP A47	FLANGE
T200HP A52	PULLEY BLADE
T200HP A58	PULLEY BLADE
T200HP A62	PULLEY TRACTOR
T200HP A77	BRUSH
T200HP A78	LOWER CENTRAL PAPER GUIDE
R/T200 HP A43	PLASTIC COVER
R 0024	BLADE DRIVE GEAR
R 0028	EJECTOR ROLLER